


WALL PLANKS INSTALLATION INSTRUCTIONS

1. Select orientation: horizontal, vertical or diagonal. Use pre-cut planks as Starter/End planks to alternate the shift of vertical seams.




2. Using a level, draw a line on the wall for the Starter Plank.



3. Prepare the finishing nails: use 1.5-1.75" finishing nails # 18 for the nail gun (adjust gun to deliver nails flush to the surface of wood), or use loose nails # 16 of 1.5-2" long for hammer installation.



4. Apply a starter plank at the line on the wall and affix it with the nails in each corner of the plank. Step at least 1 in. from each side or end of the planks. For full-length planks apply two more nails in the middle of the board. **Don't press planks against each other to leave a standard credit card (CC) thick space between boards to breathe.** If pressed the boards might try to pop out from the wall.



5. Cutting in length: use miter saw to cut boards to the desired lengths.



6. If you need to attach wall art or shelves on top of the wall planks, drill the holes and put hangers through the planks on your wall. Don't hang anything heavier than 1 lb. on the planks themselves!

7. **NOT-recommended installation options:**

- **Double-sided sticky foam** – not recommended if used alone: sooner or later the planks may fall down if you don't secure planks with nails.
- **Adhesive or liquid nails** – not recommended as many adhesives will shrink or swell while hardening and wood will be cupping. If you anyway want to use adhesive, apply it as dots on the back of the boards and secure with nails.